

27 April 2009

AgGPS FmX Integrated Display: Cleaning the Touchscreen

This document describes the procedure for cleaning the AgGPS® FmX™ integrated display's touchscreen.

Solution

The FmX integrated display touchscreen may be cleaned using the following procedure and supplies.

Recommended Supplies:

- Ammonia-free glass cleaner
- Soft, lint-free cotton cloth
- 50% isopropyl alcohol

Recommended Procedure:

Note: Do not clean the display while it is on. It is easier to see dirt and fingerprints when the display is off and the background is dark.

Caution: Do not apply the glass cleaner directly to the display.

- Apply a small amount of glass cleaner to a **lint-free, soft cotton cloth** and gently rub it against the touchscreen. Most commercially available glass cleaners are suitable for this application. If possible, use an ammonia-free cleaner.
- If stains or smudges are present, use a cotton cloth dampened with 50% isopropyl alcohol solution to remove them.

This document is for informational purposes only and is not a legally binding agreement or offer. Trimble makes no warranties and assumes no obligations or liabilities hereunder.

Trimble Navigation Limited, Agriculture Division, 10355 Westmoor Drive, Suite #100, Westminster, CO 80021, USA

© 2009, Trimble Navigation Limited. All rights reserved. Trimble, the Globe & Triangle logo, and AgGPS are trademarks of Trimble Navigation Limited, registered in the United States and in other countries. FmX is a trademark of Trimble Navigation Limited. All other trademarks are the property of their respective owners.

